B & K Business Group

Connecting Customers and Businesses Through Technology

7A Marlen Drive
Robbinsville, NJ 08691
Phone: 609-313-3055
Email: cs@bkbusinessgroup.com

Setting Sensitivity on the SK 100 (G3 or G4)

Press **SET** on mic pack

1. **Open** mic pack cover
2. Press **SET** on mic pack
3. Use up and down arrows to **Sensitivity**
4. Increase the value:
   - Typical ranges:
   - Headworn mic: -25dB to -15dB
   - Quiet speaker: closer to -20dB
5. Press **SET** on mic pack
6. Close mic pack cover
7. Test